

ENSONORDIC
SAFE BY INNOVATION

Importør:
Roliba A/S
Hvidkærvej 52
DK-5250 Odense SV

IR overvågningskamera

Simulering / dummy kamera







DK bruger vejledning

GB user manual

Importør:
Roliba A/S
Hvidkærvej 52
DK-5250 Odense SV

ENSONORDIC
SAFE BY INNOVATION

Thank you for purchasing this product. User manual deals with the most relevant features, functions and functioning of the product which enables the user to install and use the product in no time. Please read the instruction carefully in order to install and use the product properly.	GB
Realistic look camera imitation is suitable for indoor and outdoor use. Flashing red LED diode, emulation of night vision and professional appearance strengthen complete monitoring system impression and effectively discourage potential intruders. High quality housing material protects the product from adverse weather conditions, fully adjustable grip facilitates product installation.	FEATURES
weight: 250g, camera dimensions: 78*170mm, height: 170mm; lens diameter: 20mm powered by 2 x 1.5V AA batteries (not included), to switch on/off accordingly place the batteries in the product or remove it from the product casing, LED diode flashes every 2 seconds	TECHNICAL SPECIFICATION
- choose a place which you wish to protect (well visible but out of reach) - mark the points on the wall accordingly with the holes spacing in the camera base - drill holes in previously marked points - place screw anchors into the holes - mount the camera to the wall using provided screws - set the camera in desirable position - placing provided warning sticker in a visible spot will strengthen a complete monitoring system impression  Note! User manual describes installation on concrete and brick walls. In case of installation on other than recommended surfaces please purchase proper for given surface screws and anchors.	INSTALLATION
- do not expose to extreme temperatures - clean with soft, dry cloth - protect from dust and dirt - do not attempt to open the device as it can cause damage or malfunction	NOTE!
1. Slide camera's upper housing back 2. Remove the batteries placed inside of the device 3. Used out batteries and accumulators should be stored in places determined for its collection	INSTRUCTION FOR SAFE BATTERY REMOVAL
 mounting package: 3pcs anchors, 3pcs screws  camera imitation + grip  user manual	PACKAGING CONTENTS

DK	Tak for dit køb af dette produkt. Brugermanualen omhandler de mest relevante funktioner og egenskaber ved produktet, hvilket gør det muligt for brugeren at installere og anvende produktet på ingen tid. Læs venligst instruktionerne omhyggeligt for at kunne installere og bruge produktet korrekt.
Funktion	Det realistisk udseende dummykamera er velegnet til både indendørs og udendørs brug. Med en blinkende rød LED-diode, efterligning af nattevision og med et professionelt udseende, styrker udseendet kameraets samlede overvågningssystem indtryk og afskrækker effektivt potentielle indtrængere. Et høj kvalitets kabinet beskytter produktet mod ugunstige vejrforhold, og en fuldt justerbar montering letter produktinstallationen.
Teknisk specifikation	Vægt: 250 g, Kameramål: 78 x 170 mm, Højde: 170 mm, Linsediameter: 20 mm, Drevet af to stk. AA batterier - ikke inkluderet. For at tænde/slukke indsættes batterierne i produktet eller fjernes fra produktets kabinet. LED-dioden blinker hvert 2. sekund.
Installation	- Vælg et sted, der skal beskyttes (godt synligt, men utilgængeligt). - Mærk punkterne på væggen i overensstemmelse med hullernes afstand i kamerabasen. - Bor huller i de tidligere markerede punkter. - Placer plugs i hullerne. - Monér kameraet på væggen ved hjælp af de medfølgende skruer. - Juster kameraet i den ønskede position. - Husk evt. at placere en advarselssticker om overvågning et synligt sted, hvilket vil styrke indtrykket af et komplet overvågningssystem.  Bemærk! Brugermanualen beskriver installationen på beton- og murstensvægge. I tilfælde af installation på overflader, der ikke er anbefalet, skal du købe passende skruer og plugs til den pågældende overflade.
Bemærk	- Udsæt ikke for ekstreme temperaturer. - Rengør med en blød, tør klud. - Beskyt mod støv og snavs. - Forsøg ikke at åbne enheden, da det kan forårsage skade eller funktionsfejl.
Korrekt håndtering af brugte batterier	1. Skub det øverste kamerahus tilbage. 2. Fjern batterierne, der er placeret inde i enheden. 3. Brugte batterier skal håndteres korrekt og afleveres på genbrugspladsen.
PACKAGING CONTENTS	 mounting package: 3pcs anchors, 3pcs screws  camera imitation + grip  user manual